

BUCKET DRUM & STICKS



Supplies

- Bucket
- Roll of 2" clear packing tape
- (1) 5/8" x 36" wood dowel

Also

- Drill
- Jigsaw

Directions

1. Remove the handle of the bucket.
2. Drill pilot hole in bottom of bucket.
3. Starting from pilot hole, and using sidewall or base rim of bucket as a guide, cut away the bottom of bucket.
4. Begin applying packing tape. Start 2-3" below top of drum, pulling tape taut across the top and secure 2-3" below top of drum directly across top of drum.
5. Apply tape 90 degrees from first piece using same technique as above.
6. Continue applying tape across top until the entire top of the drum is covered.
7. Apply a second layer of tape across the top.
8. Be sure there are no holes.
9. Cut the wood dowel in half, creating two 18' drumsticks.



2525 Arapahoe, Boulder, CO 80302
(303) 443-1822
mcguckin.com