PVC Toddler Chair



- **Supplies & Tools** (7) 10" x 34" PVC thick-wall pipe
- (2) 6" x 34" PVC thick-wall pipe
- (4) 5" x 34" PVC thick-wall pipe
- (4) 4" x 34" PVC thick-wall pipe
- (8) Non-threaded ¾" PVC 90 degree elbows
- (6) Non-threaded 34" PVC tees
- (1) $29 \frac{1}{2}$ ' x $8 \frac{1}{2}$ ' piece of shade cloth fabric Hacksaw or PVC pipe cutter

Directions

- **Create the Toddler Chair Cover**
- 1. Fold each short end of fabric 2½" from end of fabric. 2. Sew/secure raw edge of fold to main body of fabric to

create sleeves.

Create the Toddler Chair Frame Assemble chair as indicated. Insert top and bottom sleeves of





2525 Arapahoe, Boulder, CO 80302 (303) 443-1822 mcguckin.com