

# PIPE LAMP



## Supplies

- (4) 3/4" Square Clear Bumpers
- 2' C77G Steel Chain-Gold cut to 3 equal lengths
- (1) Vintage Hairpin-style Light Bulb
- (1) Keyless Brass Lamp Socket
- (1) 8' Lamp Cord
- (1) 1/8" Steel Locknut
- (1) 3 1/4" Antique Brass Filler Canopy
- (1) In-line Rocker
- (4) 3/4" (#12 diameter) Phillips flat wood screw
- (1) 3/8" x 1/8" Black Bushing
- (6) 3/8" Black 90 degree Elbow
- (1) 3/8" Black Flange
- (3) 3/8" x Close Black Nipple
- (1) 3/8" x 2" Black Nipple
- (1) 3/8" x 3" Black Nipple
- (1) 3/8" x 6" Black Nipple
- (1) 1/2" 1/8IPS Zinc-plated Nipple
- (1) Piece of scrap wood 3/4" x 4 1/2" x 7 1/4"

## Directions

1. Set Flange on one end of scrap wood and mark center hole. Use 1/2" drill bit and drill through wood at marked hole, creating lamp base.
2. Begin threading non-socket end of lamp cord through pipe in the following order:
  - Lamp base
  - Flange
  - Close nipple
  - 90° elbow
  - Close nipple
  - 90° elbow
  - 2" nipple
  - 90° elbow
  - Close nipple
  - 90° elbow
  - 6" nipple
  - 90° elbow
  - 3" nipple
  - 90° elbow
  - Bushing
  - 1/2" zinc-plated nipple
3. Twist pipes together to form shape of lamp. Leave 2-3" of wire out of zinc-plated nipple.
4. Thread remaining wire through canopy and steel locknut. Tighten locknut onto zinc-plated nipple to secure canopy to fixture.
5. Attach wire to socket.
6. Attach flange to lamp base with flat wood screws.
7. Attach chains to holes in canopy edge.
8. Connect bottom end of chains together.
9. Attach in-line rocker to lamp cord at desired distance from lamp base.
10. Attach bumpers to bottom corners of lamp base.
11. Insert light bulb, plug in lamp, and see the light!



2525 Arapahoe, Boulder, CO 80302  
(303) 443-1822  
mcguckin.com