

PAPER PRESS



Supplies

- (2) 3/4" x 14" x 14" Plywood (1020942)
- (4) 3/8" x 4" Tap bolts (22023025)
- (4) 3/8" Wing nuts (22403035)
- (8) 3/8" Flat washers (22351135)
- Drill with 3/8" drill bit.

Directions

1. Tightly clamp plywood pieces together.
2. Mark 4 holes in each corner set 2" from closest edges.
3. Drill 3/8" holes.
4. Corner assembly order onto bolt:
 - Washer
 - Plywood
 - Blanket/Paper/blanket (from Papermaking)
 - Plywood
 - Washer
 - Wing nut
5. Tighten wing nuts evenly to press water from paper.



2525 Arapahoe, Boulder, CO 80302
(303) 443-1822
mcguckin.com